



Intelligent Precision Soldering Station

Think what you think, Have what you want



QUICK TS8



WeChat official account

www.quick-global.com



▼ Features

- Resistance type heating, rapid heating in 2 seconds, sufficient heat amount.
- Integrated design of soldering tip and heater, sensitive feedback and precise temperature control, more convenient maintenance.
- LCD, digital temperature calibration, three-channel temperature storage.
- Intelligent sleep/shutdown function, energy saving and safety, prolong the life time of the tip, heater etc.
- Use high heat-resistant silicon cable and accessories, safe to use.
- Anti-hit and anti-solder splash design of new soldering iron holder with cleaning brass, no damage to soldering tip.

▼ Standard accessories



▼ Specifications

Model	TS8
Power	150W
Display type	LCD
Operating voltage	220V AC
Temperature range	100°C~450°C
Heating principle	Resistance type
Soldering iron model	TSS80A
Tip model	TSS08 series
Heater	Integrated type
Tip-to-Ground potential	<2mV
Tip-to-Ground resistance	<2Ω
Outer dimensions	137*168*114mm
Weight	About 2.9 Kg